


Standard control panel



1. Setting the welding current
2. Display of welding current
3. Display of wire feed speed (m/min)
4. Display of current/transfer mode:
 - dip transfer
 - globular transfer (risk of weld spatter)
 - spray transfer
5. Display of material thickness
6. Display of arc length/
shape of welded bead
7. Setting welding voltage
Turn the control knob to trim/set the desired welding voltage.
8. Display of welding voltage
9. Display of +/- voltage trim
10. Display of selected program

11. Selecting program

Material - wire dimension - gas.

12. Pulse welding

MIG pulse welding on/off.

13. Selecting function On/Off

- Spot
Welding in defined spot time
- Step welding
Welding time/pause time in defined sequences
- DUO Plus™
Pulsating wire in connection with synergic MIG

14. Arc adjust


15. Memory function

5 preferred settings.

16. Menu

17. Wire feeder ID

Setting welding process MIG - Process setup



1. Setting parameters

Turn the control knob to set the desired parameter value.

2. Selecting welding parameter

Turn the control knob to select the desired welding parameter.

3. Pre-gas (sec.)

4. Softstart (m/min)

5. Hotstart (%)

6. Hotstart time (sec.)

7. Slope down (sec.)

8. Final current time (sec.)

9. Final current (%)

10. Post-gas (sec.)

11. Spot time (sec.)

12. Display of Proces/Voltage/Current

13. Return

Return to menu.

14. Function settings

Selecting between:

- Spot
 - Step
 - DUO Plus™
- Setting function parameters

15. Recall of factory settings

Reset the chosen program to factory settings.


16. Gas

- Setting manual gas/IGC (not all versions)
- Gas test
- Calibration of IGC (not all versions)


17. Machine settings

- MigaLOG
- Torch
- Service
- Language
- About


Menu - Torch



Menu - Service



Menu - Wire feeder



1. Home/return

Return to standard control panel.

2. Selecting trigger mode

2-times/4-times trigger mode.

3. Selecting torch type

Torch type.

1. Home/return

Return to standard control panel.

2. Selecting menu

- Error log
- Power module
- Wire feeder
- Wire feeder ID
- Time & date
- Reset to factory settings

1. Home/return

Return to standard control panel.

2. Wire inching forwards

3. Wire inching backwards

4. Gas test

5. Display of wire feeder information

6. Wire inching

7. Wire ID